

## OPERATING INSTRUCTIONS FOR LITER COUNTER DFZ-1-D

*P/N 14-1033-241*

*Mains voltage: 230 V/50 Hz, 12 Watt*

*Fuse: 125 mA*

The display starts to blink when the system is started first or when during use a power failure occurs. The blinking stops if the key is being turned right and then turned left again.

### **1. Setting of operation mode:**

- Turn key switch to the right (turn on)
- Open the tap valve and dispense the drink until the desired quantity is reached
- The dispense proceedings can also be interrupted
- Turn key switch again to the left (turn off), the portion quantity is programmed, the counting register is set to "0".

### **2. When dispensing a drink, a red point is running on the display (flometer control)**

### **3. Deleting the counting register**

- Turn the key to the right, the display is blinking
- By turning the key back to the left the counting register is set to "0" again

### **4. Safety instructions**

- The unit may only be installed in dry rooms
- The unit may only be opened by an competent technician. Before opening the case, pull the mains plug!
- For measuring accuracy use only 4 mm flometer
- No damages can be claimed on IMI Cornelius Österreich Ges.m.b.H. if the counting register does not record correctly.
- The enclosed operating instructions has to be given to the end-user.

CW/2/10/96